



# 99-09 GM Silverado/Sierra Regular Cab

51-510 41-510  
 52-510 42-510  
 53-510

(866) 476-6276 / (866) IRONCROSS  
 www.ironcrossautomotive.com

519 W. Dewey  
 Sapulpa, OK 74066

IRON CROSS AUTOMOTIVE INC. 2009

## TUBE STEP INSTALLATION SHEET



FIG 1



FIG 2



FIG 3

**STEP 1** Remove front and rear body mount bolts. Replace with M12 & 4-3/4" bolt, lock washer, & flat washer supplied in the bracket kit. Adding the front and rear bracket under the lower body bushing and tighten these bolts to allow for minor adjustments. (Fig 1-3) **On all 2006 and up models use factory body mount bolt.**

**STEP 2** Take one tube and bolt it to the front bracket using 1/2" bolts, lock washers, & flat washers supplied. Make sure to use the plastic o-ring supplied on the tube ends. Hand tighten the bolts making sure to leave them loose enough for final adjustments. Align the tube to your liking on the truck. Tighten the body mount bolts to 65 ft lbs first. Then tighten the tube step bolts to 65 ft lbs.

**STEP 3** Repeat the steps for the other side of the vehicle.

QTY	PARTS LIST	QTY	PARTS LIST
4	1510 Bracket	8	1/2" Flat Washer
4	M12-1.75x120MM (4 -3/4") Bolt	8	1/2" Lock Washer
4	1/2" - 13 x 1-3/4" Hex Bolt		

**For use on 52,53,42 series (extra parts for rear bracket only)**

2	1/2" Nut	2	1/2" Lock Washer
2	1/2" Flat Washer		

### MAINTENANCE AND CARE

Only use mild soap for regular cleaning. For heavy build up, a solution of ammonia and water can be used. Never use an abrasive material, i.e. steel wool, for cleaning purposes. Use terry cloth towels wiping in the direction of the tube at all times.

**FRONT and REAR brackets (4 total)**

